




Thread on the Threaded Nipple to your Pump w/ Bushing




Place float on the pump around the Nipple. Just enough of the thread will come through the middle to allow for threading on your fountainhead nozzle (If the F400, place the **Plastic Disk** around before nozzle)



Thread the nozzle on tightly as the weight of the pump will rest on the fountainhead. We recommend thread/teflon tape.



Fountains



We recommend tying a rope to your pump and running the pump's wire alongside that rope. You can create a few loops in the rope and thread the wire through if you'd like. The rope and wire will run back to the controller on the shore (see dotted line in diagram). A second rope tied to the eye of the other side of the pump can be fastened to an anchor of some sort, or the bank on the other side of the pond.



Depending on your water quality, additional filtration may be needed around the pump. Screens or perforated PVC are both options.



	Cluster	Blossom
F400	3/4"	3/4"
F1000	1"	1"